

STANDARDS

American National Standard

ANSI/NECA/BICSI 568-2006

Standard for
Installing Commercial Building
Telecommunications Cabling



Currently in preview, click buy full version

NECA/BICSI 568-2006

Standard for

Installing Commercial Building Telecommunications Cabling

An American
National Standard



Published by
National Electrical
Contractors Association



Jointly developed with



NOTICE OF COPYRIGHT

This document is copyrighted by NECA

Reproduction of these documents either in hard copy or soft (including posting on the web) is prohibited without copyright permission. For copyright permission to reproduce portions of this document, please contact NECA Standards & Safety at (301) 657-3110 ext. 546, or send a fax to (301) 215-4500.

OR

National Electrical Contractors Association
3 Bethesda Metro Center, Suite 1100
Bethesda, Maryland 20814
(301) 657-3110

Organizations may obtain permission to reproduce a limited number of copies by entering into a license agreement. For information, contact:

Global Engineering Documents
12550 Everness Way East
Englewood, CO 80112-5704 or call
1-800-854-7179 (USA and Canada)
(303) 397-7956 (International)

Table of Contents

- Foreword**v
- 1. Scope**1
 - 1.1 Products and Applications Included1
 - 1.2 Regulatory and Other Requirements1
 - 1.3 Local Code Requirements2
- 2. Definitions, Acronyms, Abbreviations, and Units of Measure** 3
 - 2.1 Definitions3
 - 2.2 Acronyms, Abbreviations, and Units of Measure13
- 3. Support Structures**14
 - 3.1 General14
 - 3.2 Pathways14
 - 3.2.1 General14
 - 3.2.2 Cable trays14
 - 3.2.3 D-rings and mushrooms16
 - 3.2.4 Conduits16
 - 3.2.5 Supports18
 - 3.2.6 Surface raceway18
 - 3.3 Spaces18
 - 3.3.1 Plywood18
 - 3.3.2 Equipment racks19
 - 3.3.3 Floor-mounted cabinets20
 - 3.3.4 Wall-mounted equipment racks and cabinets20
 - 3.4 Bonding Infrastructure20
 - 3.4.1 General20
 - 3.4.2 Bonding conductor20
 - 3.5 Installing Cable Support Systems20
 - 3.5.1 General20
- 4. Pulling Cable**24
 - 4.1 General24
 - 4.2 Cable Pulling Setup24
 - 4.2.1 Overview24
 - 4.2.2 Pulling horizontal cable in conduit25
 - 4.2.3 Pulling horizontal cable in open ceiling25
 - 4.2.4 Pulling backbone in vertical pathway—from top down25
 - 4.2.5 Pulling backbone in vertical pathway—from bottom up25

4.2.6	Pulling backbone—horizontal	25
4.2.7	Cable pulling precautions	25
5.	Firestopping	26
5.1	General	26
5.2	Typical Installations	27
5.2.1	Sealing a floor penetration with putty	27
5.2.2	Sealing an outlet box with putty	28
5.2.3	Steps—restore penetrations (general)	29
6.	Cable Terminations	31
6.1	General	31
6.2	Pre-termination Functions	31
6.3	Copper IDC Termination	31
6.3.1	General	31
6.3.2	Steps—IDC termination	32
6.4	Fiber Termination	33
6.5	Copper Cable Splicing	33
6.6	Optical Fiber Cable Splicing	34
7.	Installation Verification	35
Annex A:	Field Test Requirements	36
A.1	General	36
A.2	100-Ohm Balanced UTP Cabling	36
A.2.1	Test instruments	36
A.2.2	Performance parameters	36
A.2.3	Permanent link test configuration	36
A.2.4	Channel test configuration	37
A.2.5	Backbone and other cabling test configuration	37
A.3	Optical Fiber Cabling	37
A.3.1	Test instruments	38
A.3.2	Performance parameters	38
A.3.3	Cabling test configuration	38
A.3.4	Verifying test jumper quality	38
Annex B:	Reference Standards	41
List of Tables		
Table 1	Minimum conduit bend radius	17
Table 2	Minimum separation distances from possible sources of EMI exceeding 5kVA	22
Table 3	Preferred color coding scheme for premises cable jackets (ANSI/TIA-598-C)	24
Table 4	Color-code chart up to 600 pair	32
Table 5	Optical fiber color code chart (ANSI/TIA-598-C)	33
Table 6	Acceptable mandrel diameters for common multimode cable types (five wraps)	38

List of Figures

Figure 1	Example of structured cable system	1
Figure 2	Suspended cable tray (tubular)	14
Figure 3	Wall bracket support (tubular)	15
Figure 4	Mesh cable tray	15
Figure 5	Elevation view of cable tray installed on the rear wall of a telecommunications room	15
Figure 6	Typical backboard layout using distribution-rings	16
Figure 7	Spools (Mushrooms)	16
Figure 8	Plywood installation over drywall using toggle bolts	19
Figure 9	Tear off putty	27
Figure 10	Building bottom of penetration seal	27
Figure 11	Filling the penetration	27
Figure 12	Building top on penetration	28
Figure 13	Overlap the pad on outlet box	28
Figure 14	Second pad of putty on outlet box	28
Figure 15	Joining the pads on outlet box	28
Figure 16	Conduit penetration through masonry wall or floor	29
Figure 17	Fire seal of drywall	29
Figure 18	Fire seal cable tray penetration	30
Figure 19	Wiring schemes	31
Figure 20	Shield bond connector and braid	34
Figure 21	In-line splice configuration	34
Figure 22	Foldback splice configuration	34
Figure 23	Permanent link test configuration	36
Figure 24	Channel test configuration	37
Figure 25	Example of OLTS reference measurement (P1) with one test jumper (multimode)	39
Figure 26	Example of a measurement (P2) when verifying OLTS test jumpers (multimode)	39
Figure 27	Example of OLTS reference measurement (P1) with one test jumper (multimode)	40
Figure 28	Example of a multimode link attenuation measurement (P2)	40