

3.10.6.6 *Floodway (W5-7)*. For the use of this sign see Clause 3.10.4.



W5-7

3.10.6.7 *Low level bridge (W5-8)*. The LOW LEVEL BRIDGE sign is used to warn of an abrupt descent from the normal approach road level to the lower road level of a bridge liable to flooding.

The sign ROAD SUBJECT TO FLOODING INDICATORS SHOW DEPTH (G9-11) and the Depth Indicator (G9-22) may also be required (see Clauses 3.10.6.10 and 3.10.6.11).



W5-8

3.10.6.8 *On side road (W8-3)*. The ON SIDE ROAD sign is used as a supplement to the FERRY sign (W5-1) (see Clause 3.10.6.2) to warn of a ferry on a side road in proximity to the through road, where the normal distance requirements for placement of the sign on the side road cannot be met.

The ON SIDE ROAD sign is erected on the same post as, and below, the warning sign with which it is associated.



W8-3

3.10.6.9 *Stop here on red signal (R6-6)*. The STOP HERE ON RED SIGNAL sign may be used near the signals located at ferries and opening and one-lane bridges, and in any other situation where a vehicle is required to stop at a red signal and the position at which the vehicle must stop is not readily apparent.



R6-6