



CGA P-8.1—2016
REAFFIRMED 2022
**SAFE INSTALLATION AND
OPERATION OF PSA AND
MEMBRANE OXYGEN AND
NITROGEN GENERATORS**
FOURTH EDITION

Currently in preview, click buy full version

PREFACE

As part of a program of harmonization of industry standards, the Compressed Gas Association (CGA) has published CGA P-8.1, *Safe Installation and Operation of PSA and Membrane Oxygen and Nitrogen Generators*, jointly produced by members of the International Harmonization Council.

This publication is intended as an international harmonized standard for the worldwide use and application of all members of the Asia Industrial Gases Association (AIGA), Compressed Gas Association (CGA), European Industrial Gases Association (EIGA), and Japan Industrial and Medical Gases Association (JIMGA). Each association's technical content is identical, except for regional regulatory requirements and minor changes in formatting and spelling.

PLEASE NOTE:

The information contained in this document was obtained from sources believed to be reliable and is based on technical information and experience currently available from members of the Compressed Gas Association, Inc. and others. However, the Association or its members, jointly or severally, make no guarantee of the results and assume no liability or responsibility in connection with the information or suggestions herein contained. Moreover, it should not be assumed that every acceptable commodity grade, test or safety procedure, or method, precaution, equipment or device is contained within, or that abnormal or unusual circumstances may not warrant or suggest further requirements or additional procedure.

This document is subject to periodic review, and users are cautioned to obtain the latest edition. The Association invites comments and suggestions for consideration. In connection with such review, any such comments or suggestions will be fully reviewed by the Association after giving the party, upon request, a reasonable opportunity to be heard. Proposed changes may be submitted via the Internet at our web site, www.cganet.com.

This document should not be confused with federal, state, provincial, or municipal specifications or regulations; insurance requirements; or national safety codes. While the Association recommends reference to or use of this document by government agencies and others, this document is purely voluntary and not binding unless adopted by reference in regulations.

A listing of all publications, audiovisual programs, safety and technical bulletins, and safety posters is available via the Internet at our website at www.cganet.com. For more information, contact CGA at Phone: 703-788-2700, ext. 799. E-mail: customerservice@cganet.com.

Work Item 21-065
Atmospheric Gases and Equipment Committee

NOTE—Technical changes from the previous edition are underlined.

NOTE—No technical information has been changed from the 2016 edition. This reaffirmed edition may include minor editorial changes.

REAFFIRMED: 2022
FOURTH EDITION: 2016
THIRD EDITION: 2010
SECOND EDITION: 2003
FIRST EDITION: 1995

© 2016 The Compressed Gas Association, Inc. All rights reserved.

All materials contained in this work are protected by United States and international copyright laws. No part of this work may be reproduced or transmitted in any form or by any means, electronic or mechanical including photocopying, recording, or any information storage and retrieval system without permission in writing from The Compressed Gas Association, Inc. All requests for permission to reproduce material from this work should be directed to The Compressed Gas Association, Inc., 8484 Westpark Drive, Suite 220, McLean, VA 22102. You may not alter or remove any trademark, copyright or other notice from this work.

Contents	Page
1 Introduction.....	1
2 Scope and purpose	1
2.1 Scope	1
2.2 Purpose	1
3 Definitions.....	1
4 Health hazards	3
4.1 General.....	3
4.2 Cryogenic liquid hazards	3
4.3 Nitrogen hazards	3
4.4 Oxygen hazards	5
4.5 Protective clothing	6
5 General plant considerations.....	6
5.1 Site selection	6
5.2 Materials of construction.....	7
5.3 Cleaning	7
5.4 Electrical requirements.....	7
5.5 Fire protection.....	8
5.6 Emergency shutdown system.....	8
5.7 Noise	8
5.8 Venting	8
5.9 Dusting	9
5.10 Fluid discharge/solid disposal.....	9
5.11 Hazard review.....	9
6 Compressors	10
6.1 General.....	10
6.2 Special consideration for the compression of oxygen	10
6.3 Special consideration for the compression of nitrogen.....	10
7 Product storage	11
7.1 General.....	11
7.2 Cryogenic liquid storage	11
7.3 High pressure gas storage	11
8 Plant piping.....	11
8.1 General.....	11
8.2 Pressure relief devices	11
8.3 Pressure reducing stations.....	11
8.4 System isolation	12
8.5 Aboveground piping	12
8.6 Underground piping	12
8.7 Insulation	12
9 Operations.....	12
9.1 General.....	12
9.2 Operations checklists/log sheets	12
9.3 Procedures	12
9.4 Training.....	13
9.5 Startup.....	13
9.6 Shutdown.....	13
9.7 Remote operation and auto restart.....	14
9.8 Maintenance.....	14

10	PSA/VSA oxygen generators	15
10.1	General.....	15
10.2	Installation	16
10.3	Operating hazards.....	19
11	PSA nitrogen generators.....	20
11.1	General.....	20
11.2	Installation	22
11.3	Operating hazards.....	23
12	Membrane nitrogen generators.....	23
12.1	General.....	23
12.2	Installation	26
12.3	Operating hazards.....	26
13	Oxygen removal (deoxo) systems for nitrogen systems	26
13.1	General.....	26
13.2	Installation	28
13.3	Operating hazards.....	29
14	References	30

Table

Table 1—Effects at various oxygen breathing levels	4
--	---

Figures

Figure 1—Typical PSA/VSA oxygen generator flow diagram	16
Figure 2—Example of a small oxygen PSA	17
Figure 3—Example of an oxygen VSA	17
Figure 4—Example of an oxygen VSA.....	18
Figure 5—Example of a three-bed oxygen PSA	18
Figure 6—Example of an oxygen PSA medical unit	19
Figure 7—Typical PSA nitrogen generator flow diagram	20
Figure 8—Example of a small nitrogen generator.....	21
Figure 9—Example of a nitrogen generator	21
Figure 10—Example of a nitrogen generator	22
Figure 11—Typical membrane nitrogen flow diagram	24
Figure 12—Example of a nitrogen membrane	25
Figure 13—Example of a small nitrogen membrane.....	25
Figure 14—Typical deoxo flow diagram.....	27
Figure 15—Example of a deoxo system	28

1 Introduction

Oxygen and nitrogen generators that use pressure swing adsorption (PSA) and membrane technologies, like many present-day processes, have some degree of potential hazards that must be recognized and addressed. Common hazards associated with these generators are the asphyxiant properties of oxygen-deficient atmospheres and the ability of oxygen-enriched atmospheres to accelerate combustion. Other hazards include noise, electricity, rotating equipment, and gases under pressure.

Oxygen and nitrogen generator technology is not static. Because a wide variety of plant process cycles, equipment, and operating conditions are in use, this publication includes some generalized statements and recommendations with which there may be diversity of opinion or practice. Users of this publication should recognize that it is presented with the understanding that it cannot take the place of sound engineering judgment, training, and experience. It does not constitute, and should not be construed to be, a code of rules or regulations.

2 Scope and purpose

2.1 Scope

This publication is a guide that applies to safety in the location, installation, operation, and maintenance of certain oxygen and nitrogen generators. Included are systems using PSA and membranes for nitrogen production, PSA and vacuum swing adsorption (VSA) for oxygen production, and catalyst-based oxygen removal systems for nitrogen purification. For systems using cryogenic technologies for the production of nitrogen, oxygen, or both, see CGA P-8, *Safe Practices Guide for Cryogenic Air Separation Plants* [1]¹.

Emphasis has been placed on equipment and operational features that are unique to these system processes. Limited coverage has been given to plant equipment such as air compressors used in other industrial applications and for which safe practices in design, installation, and use have already been established elsewhere. While important supplemental equipment such as in-plant transfer piping is included, liquid backup for pipelines and cylinder filling facilities that are an adjunct to some oxygen and nitrogen generators are not covered. Also, coverage is not extended to equipment such as product transmission piping outside the generator boundaries.

While many references have been cited in this publication that give information relating to air separation plants, related equipment, and their products, the reference section is not intended to be all inclusive. Not all federal, state, provincial, territorial, or local requirements, regulations, and ordinances are listed. Further, as this publication is not intended as a universal safe practices manual for specific design and safety features, it is important to refer to the operating manuals of the equipment supplier.

2.2 Purpose

This publication is intended to serve the interest of all who may be associated with oxygen and nitrogen generator installation and operations.

3 Definitions

For the purpose of this publication, the following definitions apply.

3.1 Publications terminology

3.1.1 Shall

Indicates that the procedure is mandatory. It is used wherever the criterion for conformance to specific recommendations allows no deviation.

3.1.2 Should

Indicates that a procedure is recommended.

¹ References are shown by bracketed numbers and are listed in order of appearance in the reference section.