

**INSTITUTE OF
ENVIRONMENTAL
SCIENCES AND
TECHNOLOGY**

**Contamination Control Division
Recommended Practice 016.2**

IEST-RP-CC016.2

**The Rate of Deposition
of Nonvolatile Residue
in Cleanrooms**

INSTITUTE OF ENVIRONMENTAL SCIENCES AND TECHNOLOGY

1827 Walden Office Square, Suite 400 |
Schaumburg, IL 60173 USA
Phone: (847) 981-0100 • Fax: (847) 981-4130
E-mail: iest@iest.org • Web: www.iest.org



COPYING IS ILLEGAL
Currently in preview, click buy full version

This Recommended Practice is published by the INSTITUTE OF ENVIRONMENTAL SCIENCES AND TECHNOLOGY to advance contamination control and the technical and engineering sciences. Its use is entirely voluntary, and determination of its applicability and suitability for any particular use is solely the responsibility of the user.

This Recommended Practice was prepared by and is under the jurisdiction of Working Group 016 of the IEST Contamination Control Division.

Copyright © 2002 by the INSTITUTE OF ENVIRONMENTAL SCIENCES AND TECHNOLOGY

Second printing, July 2017

ISBN 978-1-877862-87-8

PROPOSAL FOR IMPROVEMENT: The Working Groups of the INSTITUTE OF ENVIRONMENTAL SCIENCES AND TECHNOLOGY are continually working on improvements to their Recommended Practices and Reference Documents. Suggestions from those who use these documents are welcome. If you have a suggestion regarding this document, please use the online Proposal for Improvement form found on the IEST website at www.iest.org/proposal/form.html.

INSTITUTE OF ENVIRONMENTAL SCIENCES AND TECHNOLOGY

827 Walden Office Square, Suite 400 | Schaumburg, IL 60173 USA

Phone: (847) 981-0100 • Fax: (847) 981-4130

E-mail: iest@iest.org • Web: www.iest.org

COPYING IS ILLEGAL
Currently in preview, click buy full version

The Rate of Deposition of Nonvolatile Residue in Cleanrooms

IEST-RP-CC016.2

CONTENTS

SECTION

1	SCOPE AND LIMITATIONS	7
2	BACKGROUND AND PURPOSE	7
3	REFERENCES	8
4	TERMS, DEFINITIONS, AND SYMBOLS	8
5	RATE OF DEPOSITION OF NONVOLATILE RESIDUE.....	10
6	DEPOSITION RATE CALCULATIONS.....	10
7	NVR DEPOSITION RATE LEVEL CONVERSIONS	12
8	PHYSICS OF NVR DEPOSITION	12
9	TECHNIQUES FOR MEASURING THE DEPOSITION OF NVR.....	13
10	REPORTING AND ANALYSIS OF RESULTS	19
11	BIBLIOGRAPHY	19

TABLE

1	NVR RATE LEVELS.....	11
2	CONVERSION FACTORS (1)	13
3	APPROXIMATE SENSITIVITIES OF VARIOUS AT-CUT QUARTZ CRYSTALS	17

FIGURE

1	LOCATIONS FOR SAMPLING IN A CLEANROOM OR CLEAN ZONE HAVING NONUNIDIRECTIONAL AIRFLOW AND HAVING AN AREA SMALLER THAN 15 M ² (150 FT ²).....	18
2	LOCATIONS FOR SAMPLING IN A CLEANROOM OR CLEAN ZONE HAVING NONUNIDIRECTIONAL AIRFLOW AND HAVING AN AREA BETWEEN 15 M ² (150 FT ²) AND 100 M ² (1000 FT ²).....	18
3	EXAMPLE OF LOCATIONS FOR SAMPLING IN A CLEANROOM OR CLEAN ZONE HAVING HORIZONTAL UNIDIRECTIONAL AIRFLOW.....	18
4	EXAMPLE OF LOCATIONS FOR SAMPLING IN A CLEANROOM OR CLEAN ZONE HAVING VERTICAL UNIDIRECTIONAL AIRFLOW.....	18

COPYING IS ILLEGAL
Currently in preview, click buy full version

The Rate of Deposition of Nonvolatile Residue in Cleanrooms

IEST-RP-CC016.2

1 SCOPE AND LIMITATIONS

1.1 Scope

This Recommended Practice (RP) provides a uniform method and basis for defining the rates of deposition of nonvolatile residue (NVR) and other forms of molecular contamination on surfaces in cleanrooms.

1.2 Limitations

This RP may be applied to the certification of cleanrooms or for monitoring cleanrooms to the extent agreed upon by the parties involved. In contractual agreements, the customer selects the specific measurements appropriate to the cleanroom under consideration. Specific acceptance limits are also defined in contractual agreements.

The requirements for the maximum rate of deposition of NVR should be specified by the user. The specified requirements can affect the design of the heating, ventilating, and air conditioning (HVAC) system; the selection of suitable filters, and the selection of materials used in the construction of the cleanroom. Designers, builders, and users of cleanrooms should consider specifying the maximum deposition rates as suggested by this RP if the deposition of NVR can affect the performance of products.

The techniques for measuring NVR described in this document are not the only methods that can be used, but they should be considered because of their general use. The requirements for specific products and

processes should be considered in the selection of measurement methods.

Products and procedures contained in this RP may involve hazardous materials, operations, and equipment. This RP does not purport to address all of the safety problems associated with its use. It is the responsibility of the user to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use of this RP.

2 BACKGROUND AND PURPOSE

Cleanrooms are designed to protect products from contaminants that affect the performance of those products.

Molecular contaminants, introduced by the air that enters the cleanroom or by emissions from items within the cleanroom, are deposited onto surfaces in the form of thin films or droplets; these types of deposits are called NVR. The molecular contaminants are typically transported in the air as gases or as liquid aerosols. This type of contamination is frequently referred to as airborne molecular contamination or AMC.

This RP is for use in defining the cleanroom environment and may be used in a contract with the agreement of customer and supplier. In addition, this RP is intended to complement standards on allowable NVR and molecular contaminants on products, such as IEST-STD-CC1246.