

Guide for Shoring/ Reshoring of Concrete Multistory Buildings

Reported by ACI Committee 347

ACI 347.2R-17



American Concrete Institute
Always advancing



Guide for Shoring/Reshoring of Concrete Multistory Buildings

Copyright by the American Concrete Institute, Farmington Hills, MI. All rights reserved. This material may not be reproduced or copied, in whole or part, in any printed, mechanical, electronic, film, or other distribution and storage media, without the written consent of ACI.

The technical committees responsible for ACI committee reports and standards strive to avoid ambiguities, omissions, and errors in these documents. In spite of these efforts, the users of ACI documents occasionally find information or requirements that may be subject to more than one interpretation or may be incomplete or incorrect. Users who have suggestions for the improvement of ACI documents are requested to contact ACI via the errata website at <http://concrete.org/Publications/DocumentErrata.aspx>. Proper use of this document includes periodically checking for errata for the most up-to-date revisions.

ACI committee documents are intended for the use of individuals who are competent to evaluate the significance and limitations of its content and recommendations and who will accept responsibility for the application of the material it contains. Individuals who use this publication in any way assume all risk and accept total responsibility for the application and use of this information.

All information in this publication is provided "as is" without warranty of any kind, either express or implied, including but not limited to, the implied warranties of merchantability, fitness for a particular purpose or non-infringement.

ACI and its members disclaim liability for damages of any kind, including any special, indirect, incidental, or consequential damages, including without limitation, lost revenues or lost profits, which may result from the use of this publication.

It is the responsibility of the user of this document to establish health and safety practices appropriate to the specific circumstances involved with its use. ACI does not make any representations with regard to health and safety issues and the use of this document. The user must determine the applicability of all regulatory limitations before applying the document and must comply with all applicable laws and regulations, including but not limited to, United States Occupational Safety and Health Administration (OSHA) health and safety standards.

Participation by governmental representatives in the work of the American Concrete Institute and in the development of Institute standards does not constitute governmental endorsement of ACI or the standards that it develops.

Order information: ACI documents are available in print, by download, on CD-ROM, through electronic subscription, or reprint and may be obtained by contacting ACI.

Most ACI standards and committee reports are gathered together in the annually revised ACI Manual of Concrete Practice (MCP).

American Concrete Institute
38800 Country Club Drive
Farmington Hills, MI 48331
Phone: +1.248.848.3700
Fax: +1.248.848.3701

www.concrete.org

Guide for Shoring/Reshoring of Concrete Multistory Buildings

Reported by ACI Committee 347

Kenneth L. Berndt, Chair

Matthew J. Poisel, Secretary

Rodney D. Adams
Mary Bordner-Tanck
George Charitou
Eamonn F. Connolly
James N. Cornell II
Jack L. David
Aubrey L. Dunham
Jeffrey C. Erson

Noel J. Gardner
Brian J. Golanowski
Timothy P. Hayes
Gardner P. Horst
Jeffery C. Jack
David W. Johnston
Roger S. Johnston
Robert G. Kent

Kevin R. Koogle
Jim E. Kretz
H. S. Lew
Robert G. McCracken
Eric S. Peterson
Steffen Pippig
Douglas J. Schoonover
Aviad Shapira

John M. Simpson
Ronald A. Spahr
Peter S. C. Stivaros
Daniel B. Toon
Ralph H. Tulis

This guide presents information and design criteria for shoring/reshoring operations during the construction of reinforced and post-tensioned multistory buildings. Methods for developing safe construction practices, including sequencing and timing, as well as design examples, are provided. It is written for the use of formwork engineer/contractors and engineer/architects.

Keywords: construction loads; falsework; form removal; formwork; post-tensioning; reshoring; shoring.

CONTENTS

CHAPTER 1—INTRODUCTION, p. 2

1.2—Scope, p. 2

CHAPTER 2—NOTATION AND DEFINITIONS, p. 2

2.1—Notation, p. 2
2.2—Definitions, p. 3

CHAPTER 3—SHORING/RESHORING CONSTRUCTION NEEDS, p. 3

3.1—Use of reshoring, p. 3

3.2—Types of forming systems, p. 3

CHAPTER 4—CONSTRUCTION LOADS ON FORMWORK, p. 4

4.1—Construction loads, p. 4
4.2—Load combinations, p. 4
4.3—Typical construction phases, p. 5
4.4—Construction load distribution, p. 6
4.5—Application of the simplified method, p. 6
4.6—Factors affecting the construction load distribution, p. 8
4.7—Post-tensioning load redistribution, p. 9

CHAPTER 5—STRENGTH OF CONCRETE SLABS AND FORMWORK, p. 10

5.1—Early-age concrete material strength development, p. 10
5.2—Construction load factors, p. 11
5.3—Early-age strength of concrete slabs, p. 11
5.4—Serviceability of concrete slabs, p. 12
5.5—Strength of formwork, p. 12

CHAPTER 6—CONSTRUCTION EXAMPLES, p. 12

6.1—Two-way slab construction, p. 12
6.2—Post-tensioned construction example, p. 18

CHAPTER 7—REFERENCES, p. 20

Authored documents, p. 21

ACI Committee Reports, Guides, and Commentaries are intended to provide guidance in planning, designing, executing, and inspecting construction. This document is intended for the use of individuals who are competent to evaluate the significance and limitations of its content and recommendations and who will accept responsibility for the application of the material it contains. The American Concrete Institute disclaims any and all responsibility for the stated principles. The Institute shall not be liable for any loss or damage arising therefrom.

Reference to this document shall not be made in contract documents. If items found in this document are desired by the Architect/Engineer to be a part of the contract documents, they shall be restated in mandatory language for incorporation by the Architect/Engineer.

ACI 347.2R-17 supersedes ACI 347.2R-05 and was adopted and published January 2017.

Copyright © 2017, American Concrete Institute.

All rights reserved including rights of reproduction and use in any form or by any means, including the making of copies by any photo process, or by electronic or mechanical device, printed, written, or oral, or recording for sound or visual reproduction or for use in any knowledge or retrieval system or device, unless permission in writing is obtained from the copyright proprietors.

CHAPTER 1—INTRODUCTION

In multistory cast-in-place concrete building construction, freshly cast floors are placed on formwork that is temporarily supported by a system of shores and reshores until the concrete has the ability to be self-supporting. Construction loads imposed by the shoring system can be greater than the permanent structure service load on a single floor. Construction loads can also be applied in a manner that differs from the design intent of the completed structure. Furthermore, the concrete of the supporting slabs has to attain sufficient strength, considering that the capacities of the floors below vary depending on concrete age, ambient conditions following placement, and the rate of strength development properties of the slabs. As a result, it is critical to determine the early-age load capacity of the floor slabs, including punching shear strength, to avoid the possibility of partial or total failure of the structural system. To reduce the construction load on the floor immediately below and distribute it to several lower floors or to the ground, it is necessary to add reshores. Therefore, an engineering analysis that considers both the construction load distribution and the early-age load-carrying capacity of the concrete slabs should be performed before shoring/reshoring operations begin.

Formwork failures and failures caused by improper reshoring or premature removal of supports and inadequate lateral bracing have periodically occurred throughout the history of concrete construction. Premature removal of shores and reshores prior to concrete slabs achieving the necessary strength can contribute to construction failures or defects such as permanent deflections (sagging) or cracking in the completed structure in excess of those anticipated by the design. Also, if overloaded prematurely, time-dependent deflections under load (creep) will be larger than predicted by the design and may be more noticeable and objectionable.

The schedule and process for removal of formwork, shores, and reshores should be based on an analysis of the structural effects. Except for the simplified method described in **ACI 347R** and **ACI SP-4**, there is no method universally accepted as the proper analysis of the distribution of construction loads to the floor slabs and the shoring system.

To ensure structural performance and safety during construction, a thorough understanding of construction loads applied to the slabs at early age is necessary. Equally important is knowledge of the behavior and the strength of early-age concrete members that support their own weight and construction loads.

For guidance in formwork operations, the formwork engineer/contractor can refer to several codes, standards, or guides, including **ACI 347R**, **ACI 318**, **ACI 301**, **ACI SP-4**, **ANSI/ASSE A10.9**, **OSHA 29 CFR 1926**, and **ASCE/SEI 37**. These documents provide basic guidelines for general formwork operations.

Other documents that can provide formwork design requirements or guidelines include state and local building codes, and guidelines prepared by contractors, formwork manufacturers, and other construction agencies governing construction practices.

1.2—Scope

Although the aforementioned documents provide basic guidelines for general formwork operations, there are no codes or standards that provide detailed design and construction requirements specifically for shoring/reshoring operations for multistory reinforced and post-tensioned concrete construction. Investigations for usable procedures to establish safe and cost-effective shoring/reshoring operations have been ongoing for several decades. These investigations focus on two major areas: 1) determining the distribution of loads carried by the concrete structure during construction; and 2) estimating the ability of the concrete members to resist construction loads.

This guide outlines the importance of appropriate shoring/reshoring design for multistory structures and provides basic requirements for safe construction. **ACI SP-4** serves as an expanded commentary to **ACI 347R** and provides detailed information related to formwork practices, including a discussion of shoring/reshoring procedures and analysis examples. Contract documents or the authority having jurisdiction may require the contractor to supply to the building official, upon request, the structural analysis and concrete strength requirements used in planning and implementing shoring/reshoring operations. Such data and information should be furnished to the engineer/architect who should evaluate the effects of construction loads on the immediate and long-term deflections. The contractors and formwork designers should acquire an understanding of the construction loads and the structural behavior of the buildings during construction. This understanding enables them to develop a rational shoring/reshoring system design that is economical without compromising safety, quality, and serviceability.

The objective of this guide is to present practical guidelines for the design of shoring/reshoring operations. This guide provides tools to design and evaluate construction schedules for shoring/reshoring of multistory reinforced and post-tensioned concrete structures.

CHAPTER 2—NOTATION AND DEFINITIONS

2.1—Notation

- b_o = perimeter of critical section for shear in slabs, in. (mm)
- D = design dead load, lb/ft² (kPa)
- D_c = construction dead load, lb/ft² (kPa)
- d = distance from extreme compression fiber to centroid of longitudinal tension reinforcement, in. (mm)
- E_w = reference design value for modulus of elasticity of wood, psi (MPa)
- F_c = reference design value for compression parallel to grain of wood, psi (MPa)
- f_c = compressive strength of concrete, psi (MPa)
- f'_c = specified compressive strength of concrete, psi (MPa)
- K = resulting coefficient of the governing punching shear equations from **ACI 318** that is a function of column and slab geometry
- L = design live load, lb/ft² (kPa)